

4

3

2

1

M6 BOLT THREADS INTO
THREADED BOSS IN FRAME.

NOTE: THERE IS NO HOLE ON THE
OPPOSITE SIDE OF THE TUBE.

DO NOT OVERTIGHTEN! IF IT HITS
THE INSIDE OF THE TUBE, AND YOU
OVER TIGHTEN IT, IT CAN SHEAR.

25MM AND 30MM LENGTHS ARE
BOTH INCLUDED. IF 30MM IS TOO
LONG, USE THE 25MM.

2 SPACERS ARE INCLUDED.

YOUR BIKE MAY NEED THESE TO SHIFT
THE SKID PLATE TOWARDS THE FRONT.
THERE IS A VARIANCE BETWEEN BIKES
DEPENDING ON THE YEAR THEY WERE
MADE.

IF THE MOUNTING HOLES LINE UP WELL
WITHOUT THE SPACERS, YOU CAN
DISCARD THEM.

M6 NYLOCK NUT

WASHER (TYP)

2X M6X30MM BOLTS
WITH WASHERS

M6 BOLT THRU HOLE IN FRAME
70MM AND 90MM LENGTHS ARE INCLUDED.
USE THE ONE THAT BEST FITS YOUR BIKE.

ACCESS HOLE FOR
WRENCH AND M6 NUT

HEMISPHERE
OFFROAD

XR650L SKID PLATE ASSEMBLY

4

3

2

1